



Инструкция по установке бутылочниц PTJ004F5, выдвижных секций PTJ004E5

1. Комплектация

A 1 шт.



B 1 шт.



C 2 шт.



D 2 шт.

(для 150 - 1 шт.)



E 2 шт.




F 8 шт.




G 10 шт.



2. Ширину корпуса смотрите по таблице.
Вставьте секцию в корпус.



Таблица



Название секции	W1	W2	W3	W4
PTJ004E5/F5-150	150	70	75	16
PTJ004E5/F5-200	200	110	121	62
PTJ004E5/F5-250	250	160	171	112
PTJ004E5/F5-300	300	210	221	162
PTJ004E5/F5-350	350	260	271	212
PTJ004E5/F5-400	400	310	321	262
PTJ004E5/F5-450	450	360	371	312
PTJ004E5/F5-500	500	410	421	362
PTJ004E5/F5-600	600	510	521	462

3. Установочная диаграмма. Размеры в мм

W1. W2.W3. W4 - определяйте по таблице

